



Jigsaw cordless, Type: M18FBJ5-5



Order data

Order number	078211 M18FBJ5-5
GTIN	4058546227456
Item class	03L

Description

Version:

Sturdy general-purpose jig-saws with metal gearbox casings and overload protection. On/Off switch

can be operated by either hand, thus allowing use in many different positions.

With **FIXTEC quick-release clamping system** allows blades to be changed in seconds without any tools, and **selectable orbital stroke** for optimum cutting power and dust extraction combined with reduced saw blade wear.

Cordless jigsaw, brushless POWERSTATE™ motor for high cutting power. Switch for 6 speed settings, with soft start. LED illumination of the working area.

Supplied with:

Supplied with chip break guard.

Supplied with charger, 1 × saw blade, adapter for dust extraction, dust protection hood, plastic sole plate and HD box.

Note:

Suitable spare batteries and chargers can be found under No. 073808 – 073840.

See No. 588400 – 588551 for jigsaw blades.

Packaging: Carrying case

suitable battery - supplier / battery type / voltage: Milwaukee type B 18 V

Manufacturer's designation: M18FBJ5-502X

Number of rechargeable batteries contained: 2

Type of rechargeable battery: Lithium-ion

Battery capacity: 5 Ah

Battery voltage: 18 V

Rate of strokes: 800 - 3500 rpm

Technical description

maximum vibration to EN	6.3 m/s ²
Manufacturer's designation	M18FBJS-502X
tool change without tools	yes, FIXTEC system
Mitre angle adjustment	yes
maximum sawn thickness wood	100 mm
Weight	2.8 kg
maximum sawn thickness steel	10 mm
Battery voltage	18 V
suitable battery - supplier / battery type / voltage	Milwaukee type B 18 V
Format	Straight handle
Special features	general purpose use
Rate of strokes	800 - 3500 rpm
Orbital stroke	5-way
Battery capacity	5 Ah
Type of rechargeable battery	Lithium-ion
Number of rechargeable batteries contained	2
Power supply	Rechargeable battery-powered
Packaging	Carrying case
Type of product	Saw

Accessories

Li-ion battery High Output™ Battery type, battery voltage MHB3 V

073808 MHB3

Li-ion battery High Output™ Battery type, battery voltage MHB55 V	073809 MHB55
Li-ion battery High Output™ Battery type, battery voltage MHB8 V	073810 MHB8
Li-ion battery High Output™ Rechargeable battery type, battery voltage MHB12 V	073811 MHB12
Battery starter set High Output™ Type M18HNRG3	073826 M18HNRG3
Battery starter set High Output™ Type M18HNRG55	073830 M18HNRG55
Battery starter set High Output™ Type M18HNRG8	073831 M18HNRG8
Battery starter set High Output™ Type M18HNRG12	073833 M18HNRG12
Li-ion system M18B5 Rechargeable battery type, battery voltage MB18 V	073816 MB18
Li-ion system M18B2 Battery type, battery voltage MB18 V	073827 MB18
Battery starter set Type M18NRG5	073839 M18NRG5
Jigsaw blades set Designation T118A	588400 T118A
Jigsaw blades set Designation T118B	588400 T118B
Jigsaw blades set Designation T118AF	588400 T118AF
Jigsaw blades set Designation T318A	588400 T318A
Jigsaw blades set Designation T318B	588400 T318B
Jigsaw blades set Designation T118AHM	588400 T118AHM
Jigsaw blades set Designation T127D	588400 T127D